



FIG. 2A

COPY OF PAPERS ORIGINALLY FILED





FIG.2B



F16.3

I. NVPA (NEUROVASCULAR)

QUADRATURE / PHASED ARRAY MODE

• CONFIGURATION FILE WILL TURNON ENTIRE ARRAY


• MAY BE USED FOR ALL TYPE OF BRAIN AND NECK IMAGING, EXCLUDING ECHO PLANAR IMAGING (EPI) • FOY 46CM (MAXIMUM)

RECOMMENDED USES:


BRAIN AND OR CERVICAL SPINE LOCALIZERS
IMAGING OF THE CERVICAL SPINE

IMAGING OF THE CAROTID ARTERIES

IMAGING OF THE AORTIC ARCH



OBIGINALLY FILED



F16.5

3. HRBRN (HIGH RESOLUTION BRAIN ARRAY)


 CONFIGURATION FILE WILLTURN ON ONLY. THE HEAD QUADRATURE/PHASED ARRAY MODE

USE CONFIGURATION WHEN IMAGING THE BRAIN COIL SECTION OF THE ARRAY

COMPATIBLE WITH ALL IMAGING SEQUENCES, EXCEPT EPI

• FOV 24 CM

 HIGH RESOLUTION CIRCLE OF WILLIS IMAGING HIGH RESOLUTION BRAIN IMAGING



COPY OF PAPERS